

MX9

Hand-Held Computer

Microsoft® Windows® Mobile 6.5 Operating System

User's Guide

Disclaimer

Honeywell International Inc. ("HII") reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult HII to determine whether any such changes have been made. The information in this publication does not represent a commitment on the part of HII.

HII shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of HII.

© 2011-2012 Honeywell International Inc. All rights reserved.

Web Address: www.honeywellaidc.com

RFTerm is a trademark or registered trademark of EMS Technologies, Inc. in the United States and/or other countries.

Microsoft® Windows, ActiveSync®, MSN, Outlook®, Windows Mobile®, the Windows logo, and Windows Media are registered trademarks or trademarks of Microsoft Corporation.

Marvell® is a registered trademark of Marvell Technology Group Ltd., or its subsidiaries in the United States and other countries.

Summit Data Communications, the Laird Technologies Logo, the Summit logo, and "Connected. No Matter What" are trademarks of Laird Technologies, Inc.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc.

Symbol® is a registered trademark of Symbol Technologies. MOTOROLA, MOTO, MOTOROLA SOLUTIONS and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license.

Hand Held is a trademark of Hand Held Products, Inc., a subsidiary of Honeywell International.

Wavelink®, the Wavelink logo and tagline, Wavelink Studio™, Avalanche Management Console™, Mobile Manager™, and Mobile Manager Enterprise™ are trademarks of Wavelink Corporation, Kirkland.

RAM® and RAM Mount™ are both trademarks of National Products Inc., 1205 S. Orr Street, Seattle, WA 98108.

Acrobat® Reader © 2012 with express permission from Adobe Systems Incorporated.

Other product names or marks mentioned in this document may be trademarks or registered trademarks of other companies and are the property of their respective owners.

Patents

For patent information, please refer to www.honeywellaidc.com/patents.

Limited Warranty

Refer to www.honeywellaidc.com/warranty_information for your product's warranty information.

Table of Contents

Chapter 1: Introduction	1-1
About this Guide	1-1
Laser Warnings and Labels	1-2
Label Location	1-2
Label	1-2
Components	1-3
Front	1-3
Special Purpose Keys	1-4
Special Purpose Keys - 38 Key	1-5
Top	1-6
Bottom	1-6
Back	1-7
Battery Bay	1-7
Trigger Handle	1-8
Handstrap	1-9
Label Locations	1-10
Chapter 2: Set Up A New MX9	2-1
Hardware Setup	2-1
Software Setup	2-1
Battery	2-2
Connect or Remove the Battery Pack	2-2
Insert/Replace Battery	2-2
Remove Battery	2-3
Insert Battery in HazLoc MX9	2-3
Remove Battery from HazLoc MX9	2-3
Charge or Recharge the Main Battery	2-4
Tapping the Touch Screen with a Stylus	2-5
Backlights and Indicators	2-6
Status LEDs	2-6
System Status LED	2-6
Battery Charging Status LED	2-6
Alpha mode Status LED	2-6
Bluetooth Status LED	2-6
Keypad Backlight Setting	2-6
Toggle Vibrate Indicator	2-7
Device Unlocked / Device Locked	2-8
Set Time Zone	2-9
Set Power Timers	2-10

Adjust Sounds and Notifications.....	2-11
Touch Screen.....	2-12
Calibrating the Touch Screen.....	2-12
Adjusting the Display Backlight Timer.....	2-12
Apply the Touch Screen Protective Film.....	2-12
Protect the Touch Screen when using a Holster / Carrycase.....	2-13
Holster without Handle.....	2-13
Holster with Handle.....	2-13
Carrycase.....	2-14
Using the Input Panel / Virtual Keyboard.....	2-15
Connecting Bluetooth Devices.....	2-16
Taskbar Connection Indicator.....	2-16
LED Connection Indicator.....	2-16
Setup Terminal Emulation Parameters.....	2-17
Using the AppLock Switchpad.....	2-18
Using the Keypad.....	2-18
Using the Touch Screen.....	2-18
Installing the SIM Card.....	2-19
Attaching the Handstrap.....	2-20
Attaching the Trigger Handle.....	2-21
Adjust Headset / Microphone and Secure Cable.....	2-22
Cleaning the Touch Screen and Scanner Aperture.....	2-23
Startup Help.....	2-24
Continuous Scan Mode.....	2-24
Chapter 3: Connecting Cables to the MX9.....	3-1
Connecting the USB Host and Power Cable.....	3-1
Connecting the USB Client and Power Cable.....	3-2
Connecting the Serial and Power Cable.....	3-3
Connecting an External Power Supply.....	3-4
Connecting Vehicle Power.....	3-5
DC to DC Power Supply Installation.....	3-5
Connecting Electrical Cables to Power Sources.....	3-5
Wiring Schematic.....	3-6
Connect Vehicle Electrical Connection.....	3-6
Vehicle 12V Bare Wire Adapter.....	3-8
Vehicle Cable Connection Cable (Fuse Not Shown).....	3-8
Connecting the Power Cable to the Vehicle.....	3-9
Connect Vehicle 12VDC Connection.....	3-10
Connect Power Supply to Vehicle Cradle.....	3-11

Cradle Power Connector Port	3-11
Connecting the Headset Cable.....	3-12
Connecting a Tethered Scanner.....	3-13
Chapter 4: Product Agency Compliance - MX9	4-1
Laser Light Safety Statement	4-4
Vehicle Power Supply Connection Safety Statement	4-6
Hazardous Locations Warnings.....	4-7
Chapter 5: Technical Assistance	5-1



Chapter 1: Introduction

The MX9 is a ruggedized handheld computer targeted for indoor and outdoor use. It is powered by a lightweight main battery that can be removed and replaced without the need for special tools.

MX9 wireless connectivity is secured by user-configured encryption and authentication protocols. The MX9 has an integrated keyboard, outdoor readable touch display, a tethered stylus, Microsoft® Windows® Windows Mobile 6.5 operating system, and many wireless connection options.

The keypad is available in a 62-key or 38-key configuration. The 62-key keypad is also available in an IBM 5250 configuration. Bar code reader options are: an imager or laser scanner integrated in the MX9, or a handheld scanner tethered to the port at the base of the MX9, Bluetooth mobile bar code imagers and scanners, or the Bluetooth Ring Scanner module.

Wireless network connection is accomplished using a Summit WLAN 802.11 radio, WWAN, and Bluetooth. Desk and vehicle cradles, a trigger handle or handstrap, holsters with shoulder straps or belts, clear covers for cases and holsters, Bluetooth scanners and printer, standard and low temperature batteries, and battery chargers are among the many accessories available for the MX9.

About this Guide

This MX9 User's Guide provides instruction for the end-user or system administrator to follow when setting up a new MX9.

This user's guide has been developed for a MX9 with a Microsoft® Windows® Mobile® 6.5 operating system.

Laser Warnings and Labels


- Do not look into the laser's lens.
- Do not stare directly into the laser beam.
- Do not remove the laser caution labels from the MX9.
- Do not connect the laser bar code aperture to any other device. The laser bar code aperture is certified for use with the MX9 only.

Caution



Laser radiation when open. Please read the caution labels. Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Label Location




Label



Components


Front



1. Microphone
2. Touch screen
3. Speaker
4. Scan buttons
5. Enter key
6. Scanner status LED
7. Power key


Note: The above list is the same on the 38 key MX9. Special keys are listed below.

Special Purpose Keys




1. Function Keys
2. Cursor up and down Keys
3. Diamond 1 key
4. Backspace [BS] key and Space [SPC] key
5. Escape [ESC] key
6. Power key
7. Tab key
8. Alt key
9. Control [CTL] key
10. Shift [SHFT] key
11. Blue key
12. Orange key

Special Purpose Keys - 38 Key




Top



Bar code reader aperture

Bottom




Input / Output Connector

Tethered boot cover (covers I/O connector) not shown


Back

Battery Bay




1. Battery Charging Terminals
2. Battery Bay
3. Battery Bay Access Tab

Trigger Handle




Trigger handle attach points

1. Upper
2. Lower




1. Trigger
2. Tether attach point




Stylus storage bay in trigger handle base


Handstrap



1. Handstrap
2. Handstrap Base
3. Stylus




1. Attach - Upper Handstrap Base
2. Attach - Lower Handstrap Base



1. Handstrap connector, upper
2. Stylus holder on Handstrap
3. Handstrap connector, lower

Label Locations



Device with Summit radio

1. Laser Warning Label
2. Bluetooth Label
3. Product Identification Label
4. Java Label (if installed)
5. Windows OS License Label
6. Tamper Proof Label

The tamper-proof label covers the top right screw in the battery bay. The label states "Warranty void if removed or damaged". The battery pack will not deface the label as the battery pack does not touch the label.

Chapter 2: Set Up A New MX9

This page lists a quick outline of the steps you might take when setting up a new MX9. More instruction for each step is listed later in this guide. Please refer to the *MX9 for Windows Mobile Reference Guide* for additional information and instruction.

Contact [Technical Assistance](#) if you need additional help.

Note: Installing or removing accessories should be performed on a clean, well-lit surface. When necessary, protect the work surface, the MX9, and components from electrostatic discharge.

This user's guide has been developed for a MX9 with a Microsoft® Windows® Mobile® 6.5 operating system.

While the MX9 is in a Hazardous Location DO NOT:

- Connect an external power source to the MX9.
- Connect a USB device or audio jack to the MX9.
- Remove or install a battery pack in the MX9.
- Connect a tethered scanner to the MX9.
- Place the MX9 in a powered dock or cradle.

Hardware Setup

1. Connect accessories.
2. [Connect cables](#).
3. [Insert/connect a fully charged battery](#)
4. If the screen does not automatically display, press the Power key.

Software Setup

Hardware setup should be completed before software setup begins.

1. If prompted, [calibrate Touch screen](#)
2. [Set Date and Time Zone](#)
3. [Set Power Timers](#)
4. [Set Speaker Volume](#)
5. [Pair Bluetooth devices](#)
6. Set Wireless client parameters
7. Set [terminal emulation](#) parameters
8. Suspend/resume to save changed settings
9. Set the AppLock parameters
10. Set the DCWedge parameters

Please refer to the *MX9 for Windows Mobile Reference Guide* for additional information and instruction.

Battery

Connect or Remove the Battery Pack

Warning: Never remove or replace any battery in a hazardous location.

Be sure to place the unit in Suspend Mode before removing the battery. Failing to properly place the device in Suspend mode will result in a loss of all unsaved data.

An MX9 will retain data, while the main battery is removed and replaced with a fully charged main battery, for 5 minutes.

Important: When the internal battery power is Low or Very Low connect the AC adapter to the MX9 before replacing the main battery.

Note: The battery should not be replaced in a dirty, harsh or hazardous environment. When the battery is not connected to the MX9, any dust or moisture that enters the battery well or connector may transfer to the battery/well terminals, potentially causing damage.

Warning. Only use Honeywell batteries as replacements: MX9380BATTERY 161888-0001 or 161915-0001 (Low Temperature)

Insert/Replace Battery

To insert the main battery, complete the following steps:

1. Detach the bottom hook of the handstrap (if installed).
2. Tilt the end (with the terminals) of the fully charged battery pack into the upper end of the battery compartment, and firmly press the other end until it is fully inserted into the battery compartment.
3. Push down on the battery until the retaining clip clicks into place.
4. Replace the handstrap clip in its holder (if installed).

The MX9 draws power from the battery immediately upon successful connection.

Check battery status by tapping the battery icon at the top right of the Today screen or tap **Start > Settings > System > Power > Battery**. Main battery level, internal battery level, status and other details are displayed.

Remove Battery

To remove the battery, complete the following steps:

1. Place the MX9 in Suspend mode.
2. Detach the bottom hook of the handstrap (if installed).
3. Slide the battery retaining clip down to release the main battery.
4. Pull the battery up and out of the battery well with a hinge motion.

Place the discharged battery pack in a powered battery charger.

Insert Battery in HazLoc MX9

1. Detach the bottom hook of the handstrap (if installed).
2. Tilt the end (with the terminals) of the fully charged battery pack into the upper end of the battery compartment, and firmly press the other end until it is seated into the battery compartment.
3. Push down on the battery pack until it clicks into place.
4. Place the **tethered plastic locking tab** over the battery latch, matching up the screw holes in the MX9 and the screw holes in the tethered plastic locking tab.
5. Using a flat head screwdriver, secure the battery in the battery well by securing the locking screws to the MX9 body.
6. Replace the hand strap clip in its holder.

Remove Battery from HazLoc MX9

1. Place the MX9 in Suspend mode.
2. Detach the bottom hook of the handstrap (if installed).
3. Using a flat head screwdriver, unfasten the **tethered plastic lock's** captive locking screws.
4. Place the tethered plastic locking tab to one side. Do not remove or unfasten the tether.
5. Press the battery locking tab down to release the battery pack.
6. Pull the battery up and out of the battery well with a hinge motion.

Place the discharged battery pack in a powered battery charger.

Charge or Recharge the Main Battery

Warning. Only use Honeywell batteries as replacements: MX9380BATTERY 161888-0001 or 161915-0001 (Low Temperature)

Note: The MX9 Battery Charger is designed for an indoor, protected environment. It is not authorized for use in areas designated as Hazardous Locations.

New batteries must be fully charged prior to use.

The main battery can be recharged in an AC powered Battery Charger after the battery has been removed from the MX9 or its packing material when new.

The main battery while in the MX9 can be recharged using several different methods.

Note: An external power source is required before the main battery in the MX9 will recharge.

The main battery can be recharged while it is in the MX9:

- by connecting the MX9 AC power adapter to the I/O connector at the base of the MX9.
- by docking the MX9 in a powered desk cradle
- by docking the MX9 in a powered vehicle cradle
- or by connecting the car power adapter (CLA) to the I/O connector at the base of the MX9.

Note: An uninterrupted external power source (wall AC adapters) transfers power to the computer's internal charging circuitry which, in turn, recharges the main battery and internal battery. Frequent connection to an external power source, if feasible, is recommended to maintain internal battery charge status as the internal battery cannot be recharged by a dead or missing main battery.

Tapping the Touch Screen with a Stylus

Note: Always use the point of the stylus for tapping or making strokes on the touch screen.

Never use an actual pen, pencil, or sharp/abrasive object to write on the touch screen.

Hold the stylus as if it were a pen or pencil. Touch an element on the screen with the tip of the stylus then remove the stylus from the screen.

Firmly press the stylus into the stylus holder when the stylus is not in use.

Using a stylus is similar to moving the mouse pointer then left-clicking icons on a desktop computer screen.

Using the stylus to tap icons on the touch screen is the basic action that can:

- Open applications
- Choose menu commands
- Select options in dialog boxes or drop-down boxes
- Drag the slider in a scroll bar
- Select text by dragging the stylus across the text
- Place the cursor in a text box prior to typing in data
- Place the cursor in a text box prior to retrieving data using a scanner/imager or an input/output device connected to a serial port.

A stylus replacement kit is available.

Backlights and Indicators

Status LEDs

Several LEDs are located on the front of the MX9 above the integrated speaker. They are:

- **System Status LED** indicates power management status.
- **Battery Charging Status LED** indicates main battery charging status.
- **Alpha Mode Status LED** applies to the 38-key keypad only.
- **Bluetooth Status LED** applies to Bluetooth client functions.

System Status LED

Blinking Red	Battery power fail; critical suspend
Solid Red	Main battery low
Yellow / Amber	Initial few seconds when Power key is pressed

Battery Charging Status LED

Off	No battery, no AC power, battery pack not plugged in or no AC power applied
Flashing Red	Fault, battery pack fault or failure
Yellow / Amber	Standby, battery pack temperature out of range
Red	Charging, battery pack charging (icon on touch screen)
Green	Charged, battery pack fully charged. Connected to external power.

Alpha mode Status LED

- Green when in alpha mode, 38-key keypad only.

Bluetooth Status LED

- Blue when Bluetooth activated
- Off when Bluetooth not activated.

Keypad Backlight Setting

Start > Settings > System > Options

The keypad backlight is white and can be set to be on or off.

The default value is on.

When set to off, the keypad backlight does not turn on during Suspend/Restart or reboots.

When set to on, the keypad backlight follows the display backlight settings. The keypad backlight turns off when the display backlight dims.

Toggle Vibrate Indicator

The MX9 vibration motor is activated when a scan is completed successfully (good scan vibration) or with a failure (scan key released before good scan, timeout, or rejected because of Data Options configuration).

The vibrations can be detected under the handstrap or through the trigger handle.

Use the Speaker Volume / Vibrate Icon in the top right corner of the Today screen to toggle sound and/or vibration on or off.



Vibration can also be set using Start > Settings > System > Data Collection > Notification tab. Since the Data Collection Wedge uses the operating system interface to sound beeps, if the volume/vibrate icon is set to anything other than On, Wedge beeps do not sound. Wedge vibration is not affected by these settings.

Device Unlocked / Device Locked



The MX9 can be locked manually by tapping Device unlocked on the Today screen. By default, this option is included on the Today screen. Care should be taken to not accidentally tap this area of the Today screen. Lock can be removed from the Today screen by selecting the Start > Settings > Personal > Today > Items tab.

The MX9 can also be configured to Lock automatically after a defined period of inactivity.

This setting is accessed via Start > Settings > Lock > Password tab. By default, this option is Disabled.


When the MX9 is locked, the Today screen displays Device locked by default. Click Unlock at the lower part of the screen:

- If there is no password or PIN set, click Unlock on the next screen to unlock the MX9. The MX9 is returned to normal operation.
- If there is a password or PIN set, enter the password/PIN and click Unlock. If several unsuccessful attempts are made, the MX9 can be configured to display a password hint.

Set Time Zone

Note: The first time it is powered up, or the device returns from a Clean Boot, the MX9 may reset the Time to the factory default value.


To set the Time Zone, tap the Date/Time on the Today screen or tap **Start > Settings > Clock and Alarms** icon.



Select the physical time zone. If required, adjust the time and calendar date and tap ok.

Set Power Timers

Tap **Start > Settings > Power > Advanced** tab. Adjust the timer values and tap OK. When the timer expires, the MX9 enters Suspend Mode.



Adjust Sounds and Notifications

Note: An application may override the control of the speaker volume. Turning off sounds saves power and prolongs battery life.

The speaker is located on the front of the device above the MX9 logo. The audio volume can be adjusted to a comfortable level for the listener. Operational tones are emitted from the speaker.

Sounds for Events and Programs are enabled by default. Notifications are disabled by default.



Tap the speaker icon in the top right corner. Move the slider up and down to adjust the sound. Vibrate can be toggled on and off.

Touch Screen

Calibrating the Touch Screen

If the touch screen is not responding properly to stylus taps, you may need to recalibrate the touch screen.

Recalibration involves tapping the center of a target. If you miss the center, keep the stylus on the screen, slide it over the target's center, and then lift the stylus.

To recalibrate the screen, select **Start > Settings > System > Screen > General** tab.

To begin, tap the Align Screen button on the screen with the stylus.

Follow the instructions on the screen. Tap the OK button when complete, if necessary.

Adjusting the Display Backlight Timer

Start > Settings > System > Backlight

The backlight settings use the Honeywell set of default timeouts.

When the backlight timer expires, the display backlight is dimmed, not turned off. When both checkboxes are unchecked, the backlight never turns off (or dims).

When the backlight timer expires, the display backlight and the keypad backlight turn off.

Default values are 30 seconds for Battery, 1 minute for External and both the check boxes are enabled.

Apply the Touch Screen Protective Film

First, [clean the touch screen](#) of fingerprints, lint particles, dust and smudges.


Remove the protective film from its container. Remove any protective backing from the film sheet by lifting the backing from a corner of the film. Discard the backing.

Apply the film to the touch screen starting at one side and smoothing it across the display. If air bubbles appear, raise the film slightly and continue smoothing the film across the display until it covers the glass surface of the display. If dust, lint or smudges are trapped between the protective film and the glass display, remove the protective film, clean the display and apply the protective film again.

Contact [Technical Assistance](#) about protective film packs designed specifically for your MX9 touch screen.


Protect the Touch Screen when using a Holster / Carrycase

Holster without Handle




The MX9 is inserted upside-down in the holster with the touch screen facing the belt connecting the holster to the body.

Holster with Handle



The MX9 is inserted upside-down in the holster with the touch screen facing the belt connecting the holster to the body. Guide the installed trigger handle into the trigger handle notch.

Carrycase



Remove the handstrap components from the MX9. Open the zippered case until there is enough space to insert the MX9 into the case. The touch screen must face forward so it, and the keypad, are visible through the windows in the carrycase.

Close the zippers. If desired, attach the handstrap components to the zippered case.

Using the Input Panel / Virtual Keyboard



The virtual keyboard is always available when needed e.g., text entry.

Place the cursor in the text entry field and, using the stylus:

- Tap the Shift key to type one capital letter.
- Tap the CAPS key to type all capital letters.
- Tap the áü key to access symbols.

Some applications do not automatically display the Input Panel. In this case, do the following to use the Input Panel:

- Tap the keyboard icon in the taskbar. Tapping the keyboard icon in the taskbar is a toggle action (On / Off).
- Move the cursor into the text entry field when you want to enter data using the Input Panel.

When finished entering data, tap the icon in the Taskbar again.

Connecting Bluetooth Devices

Before connecting to Bluetooth Devices:

- The system administrator has discovered, paired, connected and disconnected (using LXEZ Pairing Control Panel) Bluetooth devices for each MX9.
- The system administrator has enabled and disabled LXEZ Pairing parameters for the MX9.
- The system administrator has also assigned a Computer Friendly Name using LXEZ Pairing Control Panel for the MX9.



To connect Bluetooth devices, the MX9 should be as close as possible and in direct line of sight (distances up to 32.8 feet or 10 meters) with the targeted Bluetooth device during the discovery and pairing process.

If the devices are in Suspend, tap the power key to wake the MX9.

Using the correct procedure, wake the targeted Bluetooth device if necessary.

There may be audible or visual signals as both devices discover and pair with each other.

Taskbar Connection Indicator

	MX9 is connected to one or more of the targeted Bluetooth device(s).
	MX9 is not connected to any Bluetooth device. MX9 is ready to connect with any Bluetooth device. MX9 is out of range of all paired Bluetooth device(s). Connection is inactive.

LED Connection Indicator

When the Bluetooth LED on the MX9 is **off**, Bluetooth hardware has been turned off or it does not exist in the MX9.

When the Bluetooth LED on the MX9 is **on**:

- the MX9 is paired with another Bluetooth device but is out of range or not connected, or
- is paired and connected to another Bluetooth device, or
- is discovering other Bluetooth devices.

The Bluetooth LED

- Blinks slowly (Bluetooth LED is on for one second, off for five seconds) when it is idle.
- Blinks quickly (Bluetooth LED is on for 1/4 second, off for 2 seconds when the MX9 is discovering other Bluetooth devices.
- And blinks normally (Bluetooth LED is on for 1/2 second, off for 1/2 second) when it is connected.

There may be audible or visual signals from paired devices as they move back into range and re-connect with the Bluetooth hardware in the MX9.


Setup Terminal Emulation Parameters

Before you make a host connection, you will, at a minimum, need to know:

- the alias name or IP address (Host Address) and
 - the port number (Telnet Port) of the host system to properly set up your host session.
1. Make sure the mobile client network settings are configured and functional. If you are connecting over wireless LAN (802.11x), make sure your mobile client is communicating with the Access Point.
 2. From **Start > Program**, run **RFTerm** or tap the RFTerm icon on the desktop.
 3. Select **Session > Configure** from the application menu and select the "host type" that you require. This will depend on the type of host system that you are going to connect to; i.e., 3270 mainframe, AS/400 5250 server or VT host.
 4. Enter the "Host Address" of the host system that you wish to connect to. This may either be a **DNS name or an IP address of the host** system.
 5. Update the **telnet port number**, if your host application is configured to listen on a specific port. If not, just use the default telnet port.
 6. Select **OK**.
 7. Select **Session > Connect** from the application menu or tap the "Connect" button on the Tool Bar. Upon a successful connection, you should see the host application screen displayed.

To change options such as Display, Colors, Cursor, Bar Code, etc., please refer to these sections in the *RFTerm Reference Guide* for complete descriptions of these and other features.

Using the AppLock Switchpad



Click the switchpad icon in the taskbar.

A checkmark on the switchpad menu indicates applications currently active or available for Launching by the MX9 user. When Keyboard, on the Switchpad Menu, is selected, the default input method (Input Panel, Transcriber, or custom input method) is activated.

Using the Keypad

One switch key sequence (or hotkey) is defined by the Administrator for the end-user to use when switching between locked applications. This is known as the **Activation key**.

When the switch key sequence is pressed on the keypad, the next application in the AppLock configuration is moved to the foreground and the previous application moves to the background. The previous application continues to run in the background. MX9 key presses affect the application in focus only.

Using the Touch Screen

The figure shown above is an example and is shown only to aid in describing how the user can switch between applications using a stylus.

When the user taps the Switchpad icon with the stylus, a menu pops up listing the applications available to the user. The user can tap an application name in the popup menu and the selected application is brought to the foreground. The previous application continues to run in the background. Stylus taps affect the application in focus only. When the user needs to use the Input Panel, they tap the Keyboard option. Input Panel taps affect the application in focus only.


Installing the SIM Card

Tools required: standard size Phillips screwdriver (not supplied).

Note: Installing or removing accessories should be performed on a clean, well-lit surface. When necessary, protect the work surface, the MX9, and components from electrostatic discharge.

Note: Contact [Technical Assistance](#) if you need help when installing or removing a SIMM card.

The expansion slots in the MX9 are accessible via the hatch. The hatch can be opened using a standard size screwdriver. When the hatch is opened, the MX9 automatically shuts down. It is good practice to save any changes then perform an orderly shutdown to preserve RAM contents before opening the hatch.



When the hatch is open during this procedure, do not remove any cables or allow them to kink.


1. Summit radio card located in the back half of the MX9 assembly.
2. SIMM card located in the front half of the MX9 assembly.
3. SD card located in the front half of the MX9 assembly.

When the hatch is being closed, carefully move cables and wires back into the cavity before securing the hatch.

Before securing the hatch completely, examine the seam between the front and back half of the MX9. If the gasket is off-center, loosen the screws a little, adjust the gasket and re-tighten the screws.

Press the Power button to turn the MX9 on.

Attaching the Handstrap




1. Place the MX9 with the screen facing down, on a flat stable surface.
2. Place the handstrap base (2) in the grooved area, matching the screw holes in the handstrap base with the screw holes in the body of the MX9.
3. Insert the screws (supplied) into each of the four holes and fasten the base securely.
4. Slide the handstrap bottom clip pins into the slots at the base of the MX9 and pull the strap towards the top of the MX9 until the top clip slips into the groove.
5. Making sure the closed loop fastener surface on the handstrap are facing up, slide the strap through the latch in the top clip.
6. Fold the end of the strap over so that the closed loop fastener surfaces mate evenly and the handstrap is secured to the MX9.
7. Test the strap's connection making sure the MX9 is securely connected to each end of the strap connectors.

Check the closed loop fastener and handstrap base connection frequently. If loose, they must be tightened or replaced before the MX9 is placed into service again.

Attaching the Trigger Handle

Pressing the trigger on the trigger handle activates the integrated scanner and functions the same as the Scan key on the keypad. With the handle installed the Scan key on the keypad remains active. The trigger duplicates the operation.



- The handle is built of a durable, flexible plastic.
- The handle will not detach from the MX9 if the unit is dropped.
- The trigger handle is a mechanical device. Battery or external A/C power is not required for operation.
- The trigger handle does not need to be removed when replacing the main battery pack.
- The trigger handle might also be called a pistol grip.

Equipment needed: Torque wrench capable of torquing to 3 ± 1 in/lb ($.34\pm .11$ N/m).

Either the trigger handle or the handstrap is attached, not both. Honeywell recommends that, in the absence of a trigger handle, the handstrap be used at all times.

1. Place the MX9 with the screen facing down, on a flat stable surface.
2. Remove the handstrap, if installed.
3. Ensure that the battery can be inserted into the battery compartment before securing the trigger handle in place.
4. Attach the trigger handle to the MX9 (as shown above) with the screws provided.
5. Torque the pan head screws to 3 ± 1 in/lb ($.34\pm .11$ N/m).
6. Secure the strap tether to the trigger handle.
7. Place the stylus in the stylus holder in the trigger handle.


Periodically check the trigger handle for wear and the connection for tightness. If the handle gets worn or damaged, it must be replaced. If the trigger handle connection loosens, it must be tightened or replaced before the MX9 is placed in service.

Adjust Headset / Microphone and Secure Cable



The headset consists of an earpiece, a microphone, a clothing clip and a cable. The headset attaches to the audio cable end of the voice cable which attaches to the MX9.

Align the audio connector and the headset quick connect cable end. Firmly push the cable ends together until they click and lock in place.



Do not twist the microphone boom when adjusting the microphone. The microphone should be adjusted to be about two finger widths from your mouth.

Make sure the microphone is pointed at your mouth. Note the small "Talk" label near the mouthpiece. Make sure the Talk label is in front of your mouth. The microphone cable can be routed over or under clothing.

Under Clothing

- Leave the cable exposed only at the top of the collar.
- Be sure to leave a small loop of cable to allow movement of your head.

Over Clothing

- Use clothing clips to hold the cable close to your body.
- Tuck the cable under the belt, but leave a small loop where it goes under the belt.
- Do not wear the cable on the front of your body. It may get in your way or get caught on protruding objects.

Cleaning the Touch Screen and Scanner Aperture

Note: These instructions are for components made of glass. If there is a removable protective film sheet on the display, remove the film sheet before cleaning the screen.

Keep fingers and rough or sharp objects away from the bar code reader scanning aperture and the mobile device touch screen.

If the glass becomes soiled or smudged, clean only with a standard household cleaner such as Windex® without vinegar or use Isopropyl Alcohol. Dampen the cloth with the cleaner and then wipe the surface.

Do not use paper towels or harsh-chemical-based cleaning fluids since they may result in damage to the glass surface. Use a clean, damp, lint-free cloth.

Do not scrub optical surfaces. If possible, clean only those areas which are soiled. Lint and particulates can be removed with clean, filtered canned air.

Startup Help

Contact [Technical Assistance](#) if you need more help.

Can't change the date/time or adjust the volume.	AppLock is installed and may be running in User Mode on the MX9. AppLock user mode restricts access to the control panels.
Touch screen is not accepting stylus taps or needs recalibration.	See Also: "Calibrating the Touch Screen" when the touch screen needs recalibration, or Press Ctrl+Esc to force the Start Menu to appear. Use the tab, backtab and arrow keys to move the cursor from element to element.
MX9 seems to lockup as soon as it is rebooted.	There may be slight delays while the wireless client connects to the network, authorization for voice-enabled applications complete, and Bluetooth relationships establish or re-establish. When the desktop appears or an application begins, the MX9 is ready for use.
New MX9 main batteries don't last more than a few hours.	New batteries must be fully charged prior to first use. Li-Ion batteries (like all batteries) gradually lose their capacity over time (in a linear fashion) and never just stop working. This is important to remember – the MX9 is always 'on' even when in the Suspend state and draws battery power at all times.

Continuous Scan Mode

If Continuous Scan Mode has been enabled (factory default setting is 'Disabled'), the laser (or imager) is always on and decoding.

Caution: Laser beam is emitted continuously. Do not stare into the laser beam.


Chapter 3: Connecting Cables to the MX9

Note: Do not connect or disconnect cables in a Hazardous location.

Connecting the USB Host and Power Cable

Note: AC/DC Adapter must be assembled before this process begins.

Note: Do not connect AC power to the AC Adapter yet.




1. Holding the cable I/O connector (1), pinch the catch release buttons in until the catches are open. Connect the cable to the MX9 I/O port by matching the shape of the I/O connector on the cable with the shape of the I/O connector at the base of the MX9. Release the catch release buttons.
2. Insert the AC adapter single pin cable (2).
3. Connect the AC Adapter to a power source (wall outlet).
4. Insert the USB host plug (3) into the USB Host port.

The MX9 and the host device are connected.

Connecting the USB Client and Power Cable

Note: AC/DC Adapter must be assembled before this process begins.

Note: Do not connect AC power to the AC Adapter yet.




1. Holding the cable I/O connector (1), pinch the catch release buttons in until the catches are open. Connect the cable to the MX9 I/O port by matching the shape of the I/O connector on the cable with the shape of the I/O connector at the base of the MX9. Release the catch release buttons.
2. Insert the AC adapter single pin cable (2) .
3. Connect the AC Adapter to a power source (wall outlet).
4. Insert the USB client plug (3) into the target USB Client port.

The MX9 and the USB client are connected.

Connecting the Serial and Power Cable

Note: AC/DC Adapter must be assembled before this procedure begins.


Note: Do not connect AC power to the AC Adapter yet.



1. Holding the cable I/O connector (1), squeeze the catch release buttons in until the catches are open. Connect the cable to the MX9 I/O port by matching the shape of the I/O connector on the cable with the shape of the I/O connector at the base of the MX9. Release the catch release buttons.
2. Connect the AC adapter single pin cable end here (2).
3. Connect the assembled AC/DC Adapter to a power source (wall outlet).
4. Connect the RS232 cable end (3) to the desired serial device. Turn the thumbscrews clockwise until the connection is finger-tight.

The MX9 and the serial device are connected.

Connecting an External Power Supply



1. Connects to multi-purpose cables connected to I/O port on MX9
2. AC receptacle
3. Wall plug
4. AC connection from wall to adapter

To apply external power to the MX9 follow the steps below in sequence.

1. Plug the 3 prong AC adapter cable end of the external power assembly into an AC power source (e.g., wall outlet).
2. Firmly press the female end of the power cable into the male connector on the power adapter. When AC power is being supplied to the power adapter, the LED on the power adapter illuminates green.
3. Squeeze the catches of the I/O connector and push the cable connector into the MX9 I/O port until it clicks. The click means the connector is seated firmly.
4. Press the power cable connector pin from the power adapter into the connector on the (USB/Power or Serial/Power) cable attached to the base of the MX9. External power is now being supplied to the MX9.

Whenever possible, use the AC power adapter with the MX9 to conserve the main battery power

Connecting Vehicle Power

Complete vehicle cradle mounting and power instruction is contained in the *MX9 Cradle Guide*.

The MX9 must have a main battery installed before docking the MX9 in a cradle.

DC to DC Power Supply Installation

For use with Honeywell power supplies:

- 9000301PWRSPPLY – Power Supply, 18-60VDC with cable
- 9000302PWRSPPLY – Power Supply, 60-110VDC with cable




Connecting Electrical Cables to Power Sources

The DC to DC power supply is used to provide vehicle power to the MX9 when placed in a DC powered vehicle dock.


Specifications for Electrical Supply

Input Voltage	Always observe input voltage range specified on the DC to DC power supply
Output Voltage	12 VDC \pm 10%
Power	60 W
Fuse	5 A (slow blow fuse). Fuses are USER SUPPLIED

Note: Refer to the [Wiring Schematic](#) for wiring colors and connections.

Caution: 	For proper and safe installation, the input power cable must be connected to a fused circuit on the vehicle. This fused circuit requires a five Amp maximum time delay (slow blow) high interrupting rating fuse. If the supply connection is made directly to the battery, the fuse should be installed in the positive lead within 5 inches of the battery positive (+) terminal. Note: For North America, a UL Listed fuse is to be used.
Caution: 	For installation by trained service personnel only.
Warning: 	Risk of ignition or explosion. Explosive gas mixture may be vented from battery. Work only in well ventilated area. Avoid creating arcs and sparks at battery terminals.


Wiring Schematic



1. Existing Circuitry on Vehicle
2. Forklift Battery
3. Main Switch
4. 5A slow fuse close to power source
5. Power input
6. Isolated DC power output
7. Green
8. Red / Black
9. Red / White
10. Use color scheme corresponding to input wire provided
11. Brown
12. Blue
13. Green
14. Vehicle mounted cradle

Connect Vehicle Electrical Connection




1. The vehicle cradle must be empty.
2. Begin by connecting the power cable to the MX9's vehicle cradle. Work from this connection with the last connection being to the vehicle's power source.
3. Route the cable from the cradle to the DC to DC converter.
4. Cut the cable to length and strip the wire ends.
Route the power cable the shortest way possible. The cable is rated for a maximum temperature of 105°C (221°F). When routing this cable it should be protected from physical damage and from surfaces that might exceed this temperature. Do not expose the cable to chemicals or oil that may cause the wiring insulation to deteriorate. If the vehicle is equipped with a panel containing Silicon Controller Rectifiers (SCR's), avoid routing the power cable in close proximity to these devices. Always route the cable so that it does not interfere with safe operation and maintenance of the vehicle.
5. Remove the DC to DC converter lid screws. Put them in a safe place.
6. Remove the lid from the DC to DC converter.
7. Attach the stripped wire ends to the **output** side of the DC to DC converter.
8. Attach the stripped wire ends to the **input** side of the DC to DC converter.
9. The input and output blocks each have two + plus and two – minus connectors. Either connector in the block can be used to connect the matching polarity wire. The input and output blocks also each have two chassis ground connections. When connecting the MX9 cradle to vehicle power, use one chassis ground connector in each block.




10. Wire colors depend on the type of device attached. Please refer to [this illustration](#) for wire colors.
11. Use the looms and wire ties to secure all wiring as shown above, then reattach the cover with the screws.
12. Connect the DC to DC converter to the vehicle's electrical system.
13. While observing the fuse requirements specified [here](#), connect the power cable as close as possible to the actual battery terminals of the vehicle. When available, always connect to unswitched terminals in the vehicle fuse panel, after providing proper fusing.
Note: ATTENTION: For uninterrupted power, electrical supply connections should not be made at any point after the ignition switch of the vehicle.
14. Use proper electrical and mechanical fastening means for terminating the cable. Properly sized "crimp" type electrical terminals are an accepted method of termination. Please select electrical connectors sized for use with 18AWG (1mm²) conductors.
15. Provide mechanical support for the cable by securing it to the vehicle structure at approximately one foot intervals, taking care not to over tighten and pinch conductors or penetrate outer cable jacket.

Vehicle 12V Bare Wire Adapter

Part Number: 9000A079CBL12ML3


<p>Caution</p> 	<p>For proper and safe installation, the input power cable must be connected to a fused circuit on the vehicle. This fused circuit requires a ten Amp maximum time delay (slow blow) high interrupting rating fuse. If the supply connection is made directly to the battery, the fuse should be installed in the positive lead within 5 inches of the battery positive (+) terminal. Note: For North America, a UL Listed fuse is to be used.</p>
<p>Caution</p> 	<p>For installation by trained service personnel only.</p>
<p>Warning</p> 	<p>Risk of ignition or explosion. Explosive gas mixture may be vented from battery. Work only in well ventilated area. Avoid creating arcs and sparks at battery terminals.</p>

Vehicle Cable Connection Cable (Fuse Not Shown)



1. To Vehicle Battery
2. To Vehicle Mounted Device
3. Green (GND)
4. Brown (DC+)
5. Blue (DC-)
6. 12VDC

Connecting the Power Cable to the Vehicle



1. Vehicle Electrical System
2. 10 Amp Slow Blow Fuse
3. DC +
4. DC -
5. Vehicle Chassis
6. Brown
7. Blue
8. Green

Note: Correct electrical polarity is required for safe and proper installation. The cradle will not power on or function if the cable is connected with the polarity reversed. See the following figure titled "Vehicle Connection Wiring Color Codes" for additional wire color-coding specifics.

Connect Vehicle 12VDC Connection

1. The power cable must be UNPLUGGED from the MX9 vehicle cradle.
2. While observing the fuse requirements specified above, connect the power cable as close as possible to the actual battery terminals of the vehicle. When available, always connect to unswitched terminals in the vehicle fuse panel, after providing proper fusing.

ATTENTION: For uninterrupted power, electrical supply connections should not be made at any point after the ignition switch of the vehicle.

3. Route the power cable the shortest way possible. The cable is rated for a maximum temperature of 105°C (221°F). When routing this cable it should be protected from physical damage and from surfaces that might exceed this temperature. Do not expose the cable to chemicals or oil that may cause the wiring insulation to deteriorate.

Note: If the vehicle is equipped with a panel containing Silicon Controller Rectifiers (SCR's), avoid routing the power cable in close proximity to these devices.

Always route the cable so that it does not interfere with safe operation and maintenance of the vehicle.

Use proper electrical and mechanical fastening means for terminating the cable. Properly sized "crimp" type electrical terminals are an accepted method of termination. Select electrical connectors sized for use with 18AWG (1mm²) conductors.

Wiring color codes for Honeywell supplied DC input power cabling:

Vehicle Supply	Wire Color
+12VDC (DC +)	Brown
Return (DC -)	Blue
Vehicle Chassis (GND)	Green

4. Provide mechanical support for the cable by securing it to the vehicle structure at approximately one foot intervals, taking care not to over tighten and pinch conductors or penetrate outer cable jacket.
5. Refer to the following sections to complete the power connection to the MX9 vehicle cradle.

Connect Power Supply to Vehicle Cradle

The power cable connector is L-shaped.

The long end of the L (the cable) will be facing up towards the middle strain relief cable clamp.

Align the connector pins to the vehicle cradle Power connector; firmly pushing the connector into the Power port.


Tighten the nut of the plug clockwise until the power cable is securely fastened.

Secure the cable to the cradle with the pre-installed strain relief cable clamp (see section titled Vehicle Cradle Strain Relief Cable Clamp).

The power LED on the MX9 illuminates when it is receiving external power and an MX9 is docked.


Cradle Power Connector Port

Note: When an external power supply is used to power this cradle, the external power supply should be UL Listed, with LPS or Class 2 outputs rated 12V, minimum 2 Amps.



Pin	Signal	Wire Color
1	Ground (CG)	Green
2	Return (-)	Blue
3	+12V (+)	Brown


Connecting the Headset Cable



Headset


1. Microphone
2. Headphones
3. Connects to voice cable end of voice cable

Connect the MX9 voice cable I/O connector to the I/O port on the MX9. The MX9 internal microphone and speaker are automatically disabled.



Slide the voice cable ends together until they click shut. Do not twist or bend the connectors. The MX9 is ready for voice-enabled applications.

Connecting a Tethered Scanner



1. Connect to I/O port
2. Connect to tethered scanner

1. Squeeze the I/O port connector latches inwards. Connect part (1) of the RS232 cable to the I/O port at the base of the MX9. Release the connector latches and test the connection for stability.
2. Match the shape of the serial port (2) on the RS232 cable with the shape of the tethered scanner cable end.
3. Press the ends firmly together.
4. Secure the connection by tightening the thumbscrews on the tethered scanner cable end until they are finger tight.



Chapter 4: Product Agency Compliance - MX9

Class B Digital Device

FCC Rules, Part 15

This device complies with Part 15 of the FCC Rules [and with RSS-210 of Industry Canada]. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Notice

Changes or modifications made to this equipment not expressly approved by Honeywell may void the FCC authorization to operate this equipment.

EMC Directive Requirements

This is a Class B product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Industry Canada

This Class B digital apparatus meets all requirements of the Canadian Interference Causing Equipment Regulations. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada. Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de Classe B prescrites dans le Règlement sur le brouillage radioélectrique édictés par le ministère des Communications du Canada.

Notice

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe [] est conforme à la norme NMB-003 du Canada.*

Bluetooth and GSM technology are not available in Brazil. Bluetooth e tecnologia GSM não estão disponíveis no Brasil.

In Brazil the MX9 is not available with the MX9 AC/DC power adapter and MX9 Desktop cradle.

Waste Electrical and Electronic Equipment (WEEE)



Important:

This symbol is placed on the product to remind users to dispose of Waste Electrical and Electronic Equipment (WEEE) appropriately, per Directive 2002-96-EC. In most areas, this product can be recycled, reclaimed and re-used when properly discarded. Do not discard labeled units with trash. For information about proper disposal, visit www.honeywellaidc.com.

RF Notices

This device can contain transmitter Module(s) FCC ID:

KDZLXE4830P

KDZBT001

EO9HHSR3

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment under 47 CFR 2.1093 paragraph (d)(2).

FCC / EU RF Exposure Guidelines

Safety Information

The device complies with internationally recognized standards covering human exposure to electromagnetic fields from radio devices.

Reducing RF Exposure - Use Properly

It is advisable to use the device only in the normal operating position.

Handheld Devices

This device was tested for typical body-worn operation. Use only Honeywell tested and approved accessories to ensure FCC Compliance. The use of third-party accessories may not comply with FCC RF exposure compliance requirements, and should be avoided. To comply with FCC RF exposure requirements, this device must be operated in the hand with a minimum separation distance of 2.5 cm (0.9842 inch) or more from a person's body or with the following body-worn accessories as shown in the [applicable section of the manual](#).

- MX9420HOLSTER
- MX9423HOLSTER
- MX9410CASE
 - Shoulder strap is not approved with use with WWAN configurations

R&TTE Directive Requirements



Dealer License - Republic of Singapore

Complies with
IDA Standards
DA103458

Republic of Singapore - LXE Dealer License Number DA103458 complies with IDA Standards.

Laser Light Safety Statement



Warning: This product uses laser light. One of the following labels is provided on the scanner. Please read the Caution statement. (US)

Mise en garde: Ce produit utilise un rayon laser. L'une des étiquettes suivantes est apposée sur le scanner. Veuillez lire l'avertissement qu'elle contient. (FR)

Advertência: Este produto usa luz de laser. O scanner contém um dos seguintes avisos. Favor ler o Aviso. (PT)

Varning: Denna produkt använder laserljus. En av de nedanstående etiketterna sitter på scannern. Var god läs varningstexten. (SE)

Advarsel: Dette produkt anvender laserlys. En af følgende mærkater anvendes på scanneren. Læs venligst sikkerhedsforanstaltningen. (DK)

Varoitus: Tämä tuote käyttää laservaloa. Skannerissa on jokin seuraavista tarroista. Lue Huomio-kohta. (FI)

Warnung: Dieses Produkt verwendet Laserlicht. Eines der folgenden Etiketten befindet sich auf dem Scanner. Bitte lesen Sie den Gefahrenhinweis. (DE)

Attenzione: Questo prodotto utilizza luce laser. Una delle etichette seguenti c'è ubicata sullo scanner. Si raccomanda di leggere con attenzione le avvertenze riportate. (IT)

















Advarsel: Dette utstyret bruker laserlys. En av følgende etiketter er plassert på scanneren. Les advarselen på etiketten. (NO)

Advertencia: Este producto usa luz de láser. Las etiquetas se proveen en la máquina exploradora. Por favor, lea detenidamente la explicación para las precauciones. (ES)

Waarschuwing: Dit product gebruikt laserlicht. Een van de volgende labels is op de scanner aangebracht. Lees a.u.b. de waarschuwing onder Oppassen. (NL)

<p>Uyarı: Bu ürün lazer ışığı kullanır. Aşağıdaki etiketlerden bir tanesi tarayıcınıza üstünde sağlanacaktır. Lütfen Dikkat ifadesini okuyun. (TR)</p>	<p>Προειδοποίηση: Αυτό το προϊόν χρησιμοποιεί λέιζερ φως. Υπάρχει μία από τις ακόλουθες ετικέτες στο σαρωτή. Παρακαλούμε διαβάστε τη δήλωση με τίτλο Προσοχή. (GR)</p>
<p>경고: 본 제품은 레이저 광선을 사용합니다. 다음 라벨 중 하나가 스캐너에 제공됩니다. 주의 사항을 읽어 주십시오. (KR)</p>	<p>警告: この製品はレーザー光線を使用します。 次のラベルのうち1つがスキャナーに貼られています。 注意事項をお読みください。 (JP)</p>
<p>警告: 本产品使用激光。 下列一个标签将随扫描仪一道提供。 请阅读“当心”一栏的内容。 (CN)</p>	

Legend: Chinese – CN; Danish – DK; Dutch – NL; English – US; Finnish – FI; French – FR; German – DE; Greek – GR; Italian – IT; Japanese – JP; Korean – KR; Norwegian – NO; Portuguese – PT; Republic of China – ROC; Spanish – ES; Swedish – SE; Turkish – TR.

ENGLISH	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007 COMPLIES WITH 21 CFR 1040.10 AND 1040.11</p> <p>LASER LIGHT - DO NOT STARE INTO BEAM CLASS 2 LASER PRODUCT 1.0mW - 630 - 680nm</p>	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>RAYONNEMENT LASER NE PAS REGARDER DANS LE FAISCEAU APPAREIL A RAYONNEMENT LASER DE CLASSE 2 1.0mW - 630 - 680nm</p>	FRENCH
DANISH	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>LASERLYS KIG IKKE IND I LYSSTRÅLEN KLASSE 2 LASER PRODUKT 1.0mW - 630 - 680nm</p>	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>LASERSTRAHLUNG NICHT IN DEN STRAHL BLICKEN. LASER KLASSE 2 1.0mW - 630 - 680nm</p>	GERMAN
GREEK	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>ΠΙΠΗΤΙ ΦΩΤΟΣ LASER ΜΗΝ ΚΟΙΤΑΤΕ ΤΗΝ ΔΕΣΜΗ ΠΡΟΪΟΝ LASER ΚΛΑΣΗΣ 2 1.0mW - 630 - 680nm</p>	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>RADIAZIONE LASER NON FISSARE IL FASCIO APPARECCHIO LASER DI CLASSE 2 1.0mW - 630 - 680nm</p>	ITALIAN
NORWEGIAN	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>LASER LYS IKKE SE INN I STRÅLEN KLASSE 2 LASER PRODUKT 1.0mW - 630 - 680nm</p>	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>LUZ DE LÁSER - NO MIRE DIRECTAMENTE AL HAZ DE LUZ PRODUCTO. LASER DE LA CLASE 2 1.0mW - 630 - 680nm</p>	SPANISH
TURKISH	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>LAZER RADYASYON İŞİNA DOĞRU BAKMAYIN. CLASS 2 LAZER ÜRÜNÜ 1.0mW - 630 - 680nm</p>	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>LASERBESTRALING NIET IN DE LICHTSTRAAL STAREN. KLASS 2 LASER PRODUCT 1.0mW - 630 - 680nm</p>	DUTCH
SIMPLIFIED CHINESE	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>激光辐射 - 勿直视光束 2类激光产品 1.0mW - 630 - 680nm</p>	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>LUZ DE LASER NÃO OLHE NO RAIOS PRODUTO DE. LASER DE CLASSE 2 1.0mW - 630 - 680nm</p>	PORTUGUESE
JAPANESE	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>レーザー光線 - 光源を見つめると 危険です。クラス2レーザー製品 1.0mW - 630 - 680nm</p>	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>LASERSTRÅLNING STIRRA EJ IN ISTRÅLEN. LASERPRODUKT KLASS 2 1.0mW - 630 - 680nm</p>	SWEDISH
KOREAN	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>레이저 라이트 - 빛을 바로 쳐다보지 마십시오. 2종 레이저 상품 1.0mW - 630 - 680nm</p>	 <p>AVOID EXPOSURE - LASER RADIATION IS EMITTED FROM THIS APERTURE. EN60825-1:2007 IEC60825-1:2007</p> <p>VAARA LASERSÄTEILYÄ ÄLÄ TUJUTA SÄTEESEEN. LUOKAN 2 LASER 1.0mW - 630 - 680nm</p>	FINNISH

Vehicle Power Supply Connection Safety Statement

Vehicle Power Supply Connection: If the supply connection is made directly to the battery, a 10A slow-blow fuse should be installed in the positive lead within 5 inches (12.7 cm.) of the battery positive (+) terminal. (US)

Raccordement de l'alimentation du véhicule Si l'alimentation est raccordée directement à la batterie, un fusible à action retardée de 10A doit être installé sur le câble positif à moins de 12,7 cm de la borne positive (+) de la batterie. (FR)

EL forsyning af køretøjet. Er forsyningsforbindelsen direkte tilknyttet til batteriet og og tilsluttet til den positive part indenfor 12,7 cm (+ delen). vil der være en langsom tændelse af 10 ampere. (DK)

Kytkentä ajoneuvon virtalähteeseen Jos virtaa otetaan suoraan akusta, 10 ampeerin hidas sulake on asennettava positiiviseen johtoon enintään 12 cm:n etäisyydelle akun positiivisesta (+) navasta. (FI)

Anschluss an Fahrzeugbatterie Bei direktem Anschluss an die Fahrzeugbatterie sollte eine träge 10A-Sicherung in die positive Leitung zwischengeschaltet werden, und zwar nicht weiter als ca. 13 cm von der positiven (+) Batterieklemme entfernt. (DE)

Σύνδεση Τροφοδοτικού Ισχύος Οχήματος Αν η σύνδεση του τροφοδοτικού γίνει κατευθείαν στη μπαταρία, μια ασφάλεια βραδείας τήξης των 10Α θα πρέπει να τοποθετηθεί στο θετικό καλώδιο εντός 5 ιντσών (12,7 εκ.) του θετικού (+) ακροδέκτη της μπαταρίας. (GR)

Collegamento dell'alimentazione del veicolo Se il collegamento dell'alimentazione viene stabilito direttamente con la batteria, è necessario installare un fusibile ad azione lenta da 10A nel conduttore positivo a meno di 5 in. (12,7 cm) dal terminale positivo (+) della batteria. (IT)

Tilkople strømforsyningen til kjøretøyet Hvis strømforsyningen koples direkte til batteriet, skal det installeres en 10A treg sikring i den positive ledningen innen 12,7 cm fra plusspolen (+) på batteriet. (NO)

Ligação do fornecimento de corrente do veículo Se a ligação de fornecimento de corrente for ligada directamente à bateria, deve instalar-se um fusível de 10A no terminal positivo, a 12,7 cm. do terminal positivo (+) da bateria. (PT)

Conexión de suministro eléctrico para el vehículo Si el suministro eléctrico se proporciona directamente a la batería, se debe instalar un fusible de retardo de 10A en el conductor positivo, como máximo a 12,7 cm (5 pulgadas) del terminal positivo (+). (ES)








Fordonets strömförsörjningskoppling Om strömkopplingen görs direkt till batteriet, måste en 10A-säkring installeras i den positivt laddade ledningen inom 12.7 cm från batteriets pluspol (+). (SE)

Taşıt Güç Kaynağı Bağlantısı Kaynak bağlantısı doğrudan aküye yapılırsa, pozitif bağlantı kablosu üzerinde akünün pozitif (+) kutbuna 12.7 cm mesafede 10A'lık yavaş atan bir sigorta monte edilmelidir. (TR)

Legend: Danish – DK; English – US; Finnish – FI; French- - FR; German – DE; Greek – GR; Italian – IT; Norwegian – NO; Portuguese – PT; Spanish – ES; Swedish – SE; Turkish – TR.

Hazardous Locations Warnings

THIS EQUIPMENT IS SUITABLE FOR USE IN CLASS I, DIVISION 2, GROUPS A, B, C, D OR NON-HAZARDOUS LOCATIONS ONLY.

	WARNING - EXPLOSION HAZARD-SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR USE IN CLASS I DIVISION 2. AVERTISSEMENT - RISQUE D'EXPLOSION - LA SUBSTITUTION DE COMPOSANTS PEUT RENDRE CE MATERIEL INACCEPTABLE POUR LES EMPLACEMENTS DE CLASSE I DIVISION 2.
	WARNING - EXPLOSION HAZARD - DO NOT REPLACE BATTERIES UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HAZARDOUS. AVERTISSEMENT - RISQUE D'EXPLOSION - COUPER LE COURANT OU S'ASSURER QUE L'EMPLACEMENT EST DESIGNÉ NON DANGEREUX AVANT DE REPLACER LA BATTERIE.
	WARNING - EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HAZARDOUS. AVERTISSEMENT - RISQUE D'EXPLOSION - AVANT DE DECONNECTER L'EQUIPEMENT, COUPER LE COURANT OU S'ASSURER QUE L'EMPLACEMENT EST DESIGNÉ NON DANGEREUX.
	WARNING - Do not charge in hazardous area.
	WARNING - Separate connectors only in non-hazardous area.
	WARNING - Only use Honeywell 161888-0001 and 161915-0001 batteries as replacements.
	WARNING - EXPLOSION HAZARD. DO NOT DISCONNECT WHILE THE CIRCUIT IS LIVE OR UNLESS THE AREA IS KNOWN TO BE FREE OF IGNITABLE CONCENTRATIONS.



Chapter 5: Technical Assistance

If you need assistance installing or troubleshooting your device, please contact us by using one of the methods below:

Knowledge Base: www.hsmknowledgebase.com

Our Knowledge Base provides thousands of immediate solutions. If the Knowledge Base cannot help, our Technical Support Portal (see below) provides an easy way to report your problem or ask your question.

Technical Support Portal: www.hsmsupportportal.com

The Technical Support Portal not only allows you to report your problem, but it also provides immediate solutions to your technical issues by searching our Knowledge Base. With the Portal, you can submit and track your questions online and send and receive attachments.

Web form: www.hsmcontactsupport.com

You can contact our technical support team directly by filling out our online support form. Enter your contact details and the description of the question/problem.

Telephone: www.honeywellaidc.com/locations

For our latest contact information, please check our website at the link above.

Product Service and Repair

Honeywell International Inc. provides service for all of its products through service centers throughout the world. To obtain warranty or non-warranty service, please visit www.honeywellaidc.com and select **Support > Contact Service and Repair** to see your region's instructions on how to obtain a Return Material Authorization number (RMA #). You should do this prior to returning the product.

Limited Warranty

Honeywell International Inc. ("HII") warrants its products to be free from defects in materials and workmanship and to conform to HII's published specifications applicable to the products purchased at the time of shipment. This warranty does not cover any HII product which is (i) improperly installed or used; (ii) damaged by accident or negligence, including failure to follow the proper maintenance, service, and cleaning schedule; or (iii) damaged as a result of (A) modification or alteration by the purchaser or other party, (B) excessive voltage or current supplied to or drawn from the interface connections, (C) static electricity or electro-static discharge, (D) operation under conditions beyond the specified operating parameters, or (E) repair or service of the product by anyone other than HII or its authorized representatives.

This warranty shall extend from the time of shipment for the duration published by HII for the product at the time of purchase ("Warranty Period"). Any defective product must be returned (at purchaser's expense) during the Warranty Period to HII factory or authorized service center for inspection. No product will be accepted by HII without a Return Materials Authorization, which may be obtained by contacting HII. In the event that the product is returned to HII or its authorized service center within the Warranty Period and HII determines to its satisfaction that the product is defective due to defects in materials or workmanship, HII, at its sole option, will either repair or replace the product without charge, except for return shipping to HII.

EXCEPT AS MAY BE OTHERWISE PROVIDED BY APPLICABLE LAW, THE FOREGOING WARRANTY IS IN LIEU OF ALL OTHER COVENANTS OR WARRANTIES, EITHER EXPRESSED OR IMPLIED, ORAL OR WRITTEN, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT.

HII'S RESPONSIBILITY AND PURCHASER'S EXCLUSIVE REMEDY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT OF THE DEFECTIVE PRODUCT WITH NEW OR REFURBISHED PARTS. IN NO EVENT

SHALL HII BE LIABLE FOR INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, AND, IN NO EVENT, SHALL ANY LIABILITY OF HII ARISING IN CONNECTION WITH ANY PRODUCT SOLD HEREUNDER (WHETHER SUCH LIABILITY ARISES FROM A CLAIM BASED ON CONTRACT, WARRANTY, TORT, OR OTHERWISE) EXCEED THE ACTUAL AMOUNT PAID TO HII FOR THE PRODUCT. THESE LIMITATIONS ON LIABILITY SHALL REMAIN IN FULL FORCE AND EFFECT EVEN WHEN HII MAY HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH INJURIES, LOSSES, OR DAMAGES. SOME STATES, PROVINCES, OR COUNTRIES DO NOT ALLOW THE EXCLUSION OR LIMITATIONS OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

All provisions of this Limited Warranty are separate and severable, which means that if any provision is held invalid and unenforceable, such determination shall not affect the validity of enforceability of the other provisions hereof. Use of any peripherals not provided by the manufacturer may result in damage not covered by this warranty. This includes but is not limited to: cables, power supplies, cradles, and docking stations. HII extends these warranties only to the first end-users of the products. These warranties are non-transferable.

The duration of the limited warranty for the MX9 is 1 year.

The duration of the limited warranty for the MX9 Desktop Cradle is 1 year.

The duration of the limited warranty for the MX9 Vehicle Cradle is 1 year.

The duration of the limited warranty for the MX9 Battery Charger is 1 year.

The duration of the limited warranty for the MX9 2400mAh Li-Ion and 2100mAh Li-Ion Battery is 6 months.

The duration of the limited warranty for the MX9 AC power supply and cables is 1 year.

The duration of the limited warranty for the MX9 DC-DC Converter and cable is 1 year.

The duration of the limited warranty for the MX9 cables (USB, Serial, Communication, Power) is 1 year.

The duration of the limited warranty for the MX9 fabric accessories (e.g., belt, case, holster) is 90 days.



Honeywell Scanning & Mobility
9680 Old Bailes Road
Fort Mill, SC 29707
www.honeywellaidc.com

E-EQ-MX9WMOGWW
Rev E
10/12